


- IDEAL INSULATION FOR METAL FRAME BUILDING APPLICATIONS
- QUICK AND EASY TO INSTALL, AND ADDS R-VALUE
- REDUCES HEAT LOSS AND HEAT GAIN ALL YEAR ROUND
- WILL BLOCK UP TO 96% OF RADIANT HEAT TRANSFER

### INSTALLATION METHOD

1. Beginning at end purlin, attach rFOIL® Reflective Insulation (double-sided tape can be used if necessary to temporarily hold the product in place).
2. Unroll the reflective insulation, pull tight and continue mounting product to purlins.
3. Apply rFOIL® reflective tape to seams or use Quick-Seam tabs, if they are available.
4. Attach 3/4" - 1" strapping on top of the insulation.
5. Attach metal roofing as per usual method creating an enclosed air space between roofing and insulation.



### SUGGESTED PRODUCTS FOR THIS APPLICATION

rFOIL® INSULATION PRODUCT	2200, 2500 or 2600 Series (Available in Various Dimensions)
rFOIL® TAPES	for reflective side application 15072 or 15073   for poly side application 15852 or 15853

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of rFOIL® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of rFOIL® Reflective Insulation products and rFOIL® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if rFOIL® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using rFOIL® Reflective Insulation products near and around electrical wiring and devices.

