

INSTALLATION SHEET

NT RADIANT BARRIER (On Attic Floor Joists)



- QUICK, SAFE AND EASY TO INSTALL
- REDUCES HEAT LOSS AND HEAT GAIN ALL YEAR ROUND
- WILL BLOCK UP TO 96% OF RADIANT HEAT TRANSFER

INSTALLATION METHOD: (Cold Cimate Application)

- 1. This application involves the installation of a radiant barrier directly on the attic floor (on top of existing mass insulation).
- 2. As shown in Figure 1 and 2, the radiant barrier material should be installed perpendicular to the floor joists.
- 3. Affix the radiant barrier to the joists using regular staples, 6" apart. Be sure to leave a 6" gap around the perimeter of the attic floor, so as not to interfere with any ventilation mechanisms.



Note on Attic Ventilation:

A vented attic with a radiant barrier is a very different system from an un-vented attic with the same radiant barrier. Common types of attic ventilation are: -Soffit to Ridge -Soffit to Gable -Soffit to Soffit -Gable to Gable Most codes require at least a 1 to 300 ventilation rate. What this means is that for every 300 square feet of floor space, there should be one square foot of free vent area. Reflective Insulation Manufacturer's Association (RIMA)

SUGGESTED PRODUCTS FOR THIS APPLICATION	
rFOIL® INSULATION PRODUCT	4800P (Perforated) Series (Available in Various Dimensions)
rFOIL® TAPES	No Tape Required (Product to be Stapled)
a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement	

a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of rFOIL® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of rFOIL® Reflective Insulation products and rFOIL® makes no claims that these construction systems are universally accurate.

b) All warranties are void if rFOIL® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.

c) Exercise caution when using rFOIL® Reflective Insulation products near and around electrical wiring and devices.



279 Humberline Drive Etobicoke, ON M9W 5T6 Toll Free: 1-800-837-8961 Local: 416-798-1340 Email: sales@rfoil.com Website: www.rfoil.com Published: June 16, 2022

