


- IDEAL INSULATION FOR METAL FRAME BUILDING APPLICATIONS
- QUICK AND EASY TO INSTALL, AND ADDS R-VALUE
- REDUCES HEAT LOSS AND HEAT GAIN ALL YEAR ROUND
- WILL BLOCK UP TO 96% OF RADIANT HEAT TRANSFER

INSTALLATION METHOD

1. Starting at the ridge, unroll rFOIL™ insulation perpendicular to the purlins.
2. Using 1 1/4" self-tapping screws, attach end of the roll to ridge (screws spaced 8" apart).
3. Continue installing insulation towards roof's edge, allowing the insulation to sag approximately 3/4" between purlins.
4. Unroll the second roll of insulation as in step (1) and attach the two sections together using the Quick-Seam tab (if applicable) or the rFOIL™ tape.
5. Install first course of metal roofing section, in accordance with the manufacturer's instructions.
6. Repeat steps 1-5 for the remainder of the roof.



SUGGESTED PRODUCTS FOR THIS APPLICATION:

rFOIL™ INSULATION PRODUCT	2600, 2200, or 2500 Series (Available in Various Dimensions)
rFOIL™ TAPE	15013, 15012 (Reflective), 15853, 15852 (White Poly)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of rFOIL™ Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of rFOIL™ Reflective Insulation products and rFOIL™ makes no claims that these construction systems are universally accurate.
- b) All warranties are void if rFOIL™ Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using rFOIL™ Reflective Insulation products near and around electrical wiring and devices.

