


- IDEAL FOR MINI STORAGE BUILDINGS WITH FLAT, GABLE, AND SINGLE SLOPE ROOFING
- QUICK AND EASY TO INSTALL, WHILE ADDING R-VALUE
- REDUCES HEAT LOSS AND HEAT GAIN ALL YEAR ROUND
- CAN BLOCK UP TO 96% OF RADIANT HEAT TRANSFER

INSTALLATION METHOD

1. Measure distance from eave to eave.
2. To ensure rFOIL™ insulation is applied level and in-line, snap a chalk line along the length that the insulation will run.
3. Cut a piece of rFOIL™ insulation slightly longer than the length measured in step (1). This extra length will allow the material to drape between purlins.
4. Apply double-sided tape to the eaves. Unroll rFOIL™ insulation from the ridge, draping material between purlins. Allow material sag approximately ¾" to create the necessary airspace.
5. Fasten material to eave using double-sided tape. If necessary, use mechanical fasteners such as self tapping screws.
6. Install first metal roofing piece as per manufacturer's instructions.
7. Repeat steps 3-6 for the remainder of the insulation and roofing.
8. Seal all seams and butt joints using rFOIL™ tape to ensure a continuous vapour barrier.



SUGGESTED PRODUCTS FOR THIS APPLICATION:

rFOIL™ INSULATION PRODUCT	2600, 2200, or 2500 Series (Available in Various Dimensions)
rFOIL™ TAPE	15013, 15012 (Reflective), 15853, 15852 (White Poly)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of rFOIL™ Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of rFOIL™ Reflective Insulation products and rFOIL™ makes no claims that these construction systems are universally accurate.
- b) All warranties are void if rFOIL™ Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using rFOIL™ Reflective Insulation products near and around electrical wiring and devices.



279 Humberline Drive Etobicoke, ON M9W 5T6
 Call Toll Free: 1-800-837-8961 Local: 416-798-1340
 Fax: 416-798-1342 Email: sales@rfoil.com
Visit our Website: www.rfoil.com

